



**Eddie Bauer® Ladies Smooth Fleece Full-Zip.  
EB247**

**PRODUCT MEASUREMENTS**

	XS	S	M	L	XL	2XL	3XL	4XL
Body Length at Back	26 1/2	27	27 1/2	28	28 1/2	29	29 1/2	30
Bust	17 1/4	18 1/4	19 1/4	20 3/4	22 1/4	23 3/4	25 3/4	27 3/4
Sleeve	32	32 1/2	33	33 5/8	34 1/4	34 7/8	35 1/4	35 5/8

**BODY LENGTH AT BACK**

Measured from high point shoulder to finished hem at back.

**BUST**

Measured across the chest one inch below armhole when laid flat.